



The Processall Prestovac® Reactor is suitable for slurring a leafy or fibrous product into a solvent to aid in removing all the flavors with minimum losses. With the Prestovac, the extraction takes place under pressure to help release all the flavors to the solvent. Subsequently, the vapors are condensed and the slurry is either filtered in the Filt-A-Dry or pressed with a screw press. The slurring process can be repeated to assure that all the flavors are captured. The final filter cake can then be vacuum dried to recover all the solvent prior to disposal.

*The benefits of the Processall solvent extraction system are:*

- Better flavor yield due to enhanced mixing and chopping.
- Extraction is carried out under pressure to drive flavors out of the fibrous structure of the bean or root.
- Multi-processing in one vessel, avoiding flavor losses and expensive material transfer.
- Safer system with the self-contained vessel, avoiding environmental exposure to solvents.
- The resulting filter cake can then be dried in the same vessel by removing and recovering the solvents. This will save disposal cost and allow reuse of the solvent.

The Continuous Vacuum Dryer/Reactor is a horizontal mixing device with central shaft equipped with mixing elements perpendicular to the shaft. Multi-mixing elements in conjunction with adjustable weirs are provided to introduce the product through different processing zones for thermal treatment or conducting chemical reactions. The device incorporates a heating or cooling jacket.